AD-4971 SERIES METAL DETECTOR





AD-4971 SERIES

Provides high sensitivity detection with simple and easy operation and contributes to the delivery of safe products to your customers.

» High sensitivity detection

You can conduct high sensitivity detection with simple and easy operation. The optimal sensitivity setting can be set through the auto sensitivity settings. The phase tracking function enables minimization of product phase and allows constant high sensitivity inspection.

The display utilizes a high visibility » 7 inch color touch panel color LCD with friendly touch panel Graphic User Interface (audio quidance support function included).

Product images can be » Image import quickly uploaded to the metal from USB detector from a USB memory, making product identification and upload fast and simple.

» Stores up to 1000 products

Products can be divided into 10 different groups with up to 100 products able to be recorded within each group.

Protected from dust and water to IP65 standards. Hygienic design with the entire system washable.



Display Examples







» Modbus® communication Equipped with Modbus RTU/Modbus TCP as standard. With Modbus communication, seamless connection can be easily achieved.

Operations such as stopping and starting inspection, collecting data and changing product can all be set from an external device.



Touch Panel PC AD-4971 Metal Detector AD-4961 Checkweigher

METAL DETECTOR

function

» History Operational History

The history of configuration changes can be recorded and displayed. Suitable for use in HACCP programs along with the weighing history function.

Users can be registered and their scope of permitted operations controlled according to 4 management levels.


[Operator]

[Supervisor]

[Quality Manager]


[Administrator]

By assigning each user to the appropriate level of access, inadvertent operations can be avoided. *



Inspection History

Inspection results, such as date, time, group, and product codes and inspection results, can be recorded to USB memory during inspection.




» Data output All inspection data (csv), operation history Graph printing Inspection results and to USB (csv), inspection summary data (PDF) and operation check results (PDF) can be outputted to USB memory.

* USB memory is not included. Please prepare separately

to a printer operation check results can be outputted to a PostScript printer via Ethernet.


Basic Prinicple of Metal Detection

A sensor head of an electromagnetic induction type metal detector consists of a transmitter coil and two receiver coils that are equally spaced and are differentially connected. A transmitter coil broadcasts a radio frequency signal and generates an electromagnetic field between the transmitter coil and receiver coils. When no contaminant exists, both receiver coils receive an equal amount of magnetic flux and differential signal output is balanced at zero. The magnetic flux balance is disturbed and creates a differential output signal when a contaminant passes through the aperture. Metal detectors detect metal contaminants by proccessing this differential output signal.




^{* &}quot;Operator" is set when the power is turned on.

AD-4971 Series Specifications









AD-4971-3525

Aperture size: 350 mm (W) x 250 mm (H) 13.7 in (W) x 9.8 in (H) (Pass height 230 mm / 9 in) Detection sensitivity ' Fe: Ø0.7 mm, SUS: Ø 1.5 mm






AD-4971-4517

Aperture size: 450 mm (W) x 170 mm (H) 17.7 in (W) x 6.7 in (H) (Pass height 150 mm / 5.9 in Detection sensitivity * Fe: Ø0.5 mm, SUS: Ø 1.0 mm

Aperture size: 450 mm (W) x 250 mm (H) 17.7 in (W) x 9.8 in (H) (Pass height 230 mm / 9 in)

AD-4971-4525

Detection sensitivity * Fe: Ø0.7 mm, SUS: Ø 1.5 mm



^{*} Detection sensitivity will change depending on product and environmental conditions. Please prepare a ϕ 4-7mm power cable.

*Optional tower lights are illustrated in blue.

Common Specifications for AD-4971 Series

Transport medium	Urethane belt
Conveyor belt speed	10 ~ 60 m/min 32.8 ~ 196.8 ft/min
Display	7 inch touch panel color display
Operation method	Touch panel (WVGA), key switch
Number of recorded items	1,000 items
Communication functions	Modbus TCP / Modbus RTU / TCP/IP
	(PostScript Printer)
	USB (for USB memory, data storage, image
	import use)
External input	Non-voltage contact input 4 points
External output	Relay outut 8 points
Dust / water resistance	IP65 compliant
specifications	
Operation temperature / humidity range	$0 \sim 40^{\circ}\text{C} / 32 \sim 104^{\circ}\text{F}$ humidity below 85% (with no condensation)
Power supply	Single phase AC100V -240V (+10% / -15%), 50/60Hz 180 VA
Material	Sensor head: Stainless steel
	Display: ABS resin
	Conveyor unit: Phenolic resin, stainless steel,
	Aluminum (alumite treatment)
	Control box: ABS resin / optional stainless steel
	Base unit: Stainless steel

Operating precautions

- 1. Decide where in the production proccess to install the metal detector by assessing the risk of metal contamination.
 - » For raw materials with a lot of metal contaminants, install a metal detector before processing begins.
 - » For products packed in aluminum foil packages, install a metal detector before the packaging process.
 - » For frozen products, install a metal detector after freezing (make sure the product is frozen to the core and it's below -18°C).
- 2. Production flow of horizontally long or oblique orientation is preferable.
- 3. Keep inspected products as small as possible.
- 4. Keep product temperature constant.
- 5. Installing the metal detector in an area with little vibration is advised.
- 6. Dedicated 100-240V wiring with low noise is advised.
- Make sure to ground the metal detector.
- Remove vibrating or shifting metals near the sensor head.
- 9. Make sure thta ground loops are not created by nearby equipment.
- 10. Please prepare a Ø4-7 mm power cable.





1756 Automation Parkway San Jose, CA 95131 (800) 726-3364 or (408) 263-5333 Email: info@andinspection.com www.andinspection.com

